


INSTALLATION INSTRUCTIONS FOR SINGLE END EXPANSION JOINT - FEJ1



Note: Packing adjusting nuts are only finger tight - see instructions.

Formula for Initial Installation Setting

$$\frac{\text{MAXIMUM TEMPERATURE} - \text{INSTALLATION TEMPERATURE}}{\text{MAXIMUM TEMPERATURE} - \text{MINIMUM TEMPERATURE}} \times 10 = \text{Initial Setting (in.)}$$

Note: Expansion Joint Shipped in the closed position with expansion of 10" available.

Installation

1. Move Limit Rod Nuts to initial setting as calculated from closed position. Expand joint to this position. Attach both joint ends to main line pipe.
2. Make final adjustments of Limit Rod Nuts as follows: TOTAL AVAILABLE EXPANSION (10") – INITIAL SETTING = DISTANCE OF NUTS FROM LIMIT RING.
3. Make sure pipe is properly aligned to assure ease of expansion.
4. Tighten Packing Adjusting Nuts to 60 ft.-lbs.
5. Apply water pressure and test for leaks. If leaks appear around slip pipe, tighten packing adjusting nuts evenly until leak stops.



The Ford Meter Box Co., Inc. 775 Manchester Avenue, P.O. Box 443, Wabash, Indiana, USA 46992-0443
Telephone: 260-563-3171 FAX: 800-826-3487 Overseas FAX: 260-563-0167 <http://www.fordmeterbox.com>