

## **RECTANGULAR ANCHOR FLANGE INSTALLATION**

1. Place and secure the lid (locking or lockless) in the flange before tightening the set screws to insure the box upper section and flange are properly aligned.
2. The anchor flange is secured to the upper section of the meter box (iron or plastic) by tightening the four set screws.



The Ford Meter Box Company, Inc.  
P.O. Box 443, Wabash, IN 46992