

# 3"-12" Restrained Coupling Kit Assembly (RCKIT) Instructions

Refer to the FMB website (<http://www.fordmeterbox.com>) for additional and most recent instructions and product information.



1. Check to ensure the parts are not damaged. Remove any dust or debris from gaskets and sealing surface of the coupling sleeve.



2. Lubricate around the entire outside curvature of the SO-EZ gaskets with an approved pipe lubricant meeting AWWA C111. Install a SO-EZ gasket onto the MJ lip of each restraint gland.



3. Assemble a nut on one end of each restraint rod to approximately two nut widths. Install the restraint rods through one restraint gland with the SO-EZ gasket facing inside the assembly. Stand the assembly on a flat surface with nut side down.



4. Place sleeve on gasket/gland assembly. Install the second restraint gland and SO-EZ gasket on the other sleeve end with the gasket facing inside the assembly. Make sure the rods extend through the holes of the restraint gland.



5. Loosely assemble a nut on the other end of each restraint rod.

**If using FORD restraints, please follow additional enclosed installation instructions for the installation of the coupling on the pipe. Additionally, if not using a FORD restraint gland, please follow the instructions of the restraint manufacturer.**



**The Ford Meter Box Co., Inc.** 775 Manchester Avenue, P.O. Box 443, Wabash, Indiana, USA 46992-0443  
Telephone: 260-563-3171 FAX: 800-826-3487 Overseas FAX: 260-563-0167 <http://www.fordmeterbox.com>